

**JANAM**

**XT1 Rugged Mini-Tablet**  
Quick Start Guide

*Technology at Work.®*

---

## **XT1 Rugged Mini-Tablet** Quick Start Guide

---

Copyright 2014 Janam Technologies LLC. All rights reserved.

XT1 Rugged Mini-Tablet, Janam and the Janam logo are trademarks of Janam Technologies LLC. Other product and brand names may be trademarks or registered trademarks of their respective owners.

Janam Technologies LLC assumes no responsibility for any damage or loss resulting from the use of this guide. Janam Technologies LLC assumes no responsibility for any loss or claims by third parties which may arise through the use of this product. Janam Technologies LLC assumes no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery or repairs. To protect against data loss, be sure to make backup copies (on other media) of all important data.

Follow all usage, charging and maintenance guidelines in the Product User Guide. If you have questions, contact Janam. For a copy of the Product User Guide, visit [www.janam.com](http://www.janam.com).

**Important:** Please read the End User License Agreement for this product before using the device or the accompanying software program(s). Using the device or any part of the software indicates that you accept the terms of the End User License Agreement.

---

## Content and Additional Resources

---

To help you get started with your XT1 Rugged Mini-Tablet, this guide features:

- Hardware Overview
- Getting Started
  - A. Charging the Battery
  - B. Turning Device On and Off
  - C. Navigating the Touch Screen
  - D. Accessing the SIM Card Slot and microSD Card Slot
  - E. Getting Connected

Contents of this guide are subject to change. For the most current version of this guide and additional product details, visit [www.janam.com](http://www.janam.com).


For software updates and information, visit [www.android.com](http://www.android.com)

---

## Hardware Overview

---

1. LED Indicator 1 (barcode reader status)
2. LED Indicator 2 (battery charge status)
3. Barcode Reader
4. Power Button
5. Speaker
6. Rear Camera
7. Flash
8. Front Camera
9. Microphone
10. HD Connector
11. Mini-USB Port
12. Dock Connector
13. Headphone Socket
14. Lanyard Holder
15. Micro SIM Card Slot
16. Volume Up/Programmable Button
17. Volume Down/Programmable Button
18. Memory Card Slot



---

## Getting Started

---

### A. CHARGING THE BATTERY

To charge the battery using the included **USB AC Adapter**:

1. Insert the mini-USB end of the USB cable into the mini-USB port on the XT1 unit.
2. Plug in the AC Adapter. Use only easily accessible wall sockets that are easily reached with the length of supplied power cable.

To charge the battery using your **PC USB Port**:

1. Connect the USB cable to the PC. Use only a USB-IF compliant USB port as a charging source.
2. Insert the mini-USB end of the USB cable into the mini-USB port on the XT1 unit.

To charge the battery using an **XT1 Cradle Kit**:

1. Connect the power supply to the cradle, then connect the line cord to the power supply.
2. Plug in the power supply. Use only easily accessible wall sockets that are easily reached with the length of supplied power cable.
3. Place the device in cradle. The LED on the device will illuminate to confirm connection.
4. The battery is fully charged in approximately 2 hours.

### B. TURNING DEVICE ON/OFF

1. To turn on your device, press and hold the Power key.
2. If you are turning on your device for the first time, follow the on-screen instructions to set up your XT1 Rugged Mini-Tablet.
3. To power off the device, press and hold the Power key, and then select Power Off.

---

## Getting Started (continued)

---

### C. NAVIGATING TOUCH SCREEN

1. Remove the screen protection film before using your XT1 Rugged Mini-Tablet.
2. Tap the touch screen with your fingertip to activate. Avoid direct contact with sharp objects, including stylus and pen.
3. Tap the screen once to select or open a menu, option or application. Tap an item and drag with your finger to move to a new location.
4. Screen can be viewed in portrait or landscape mode and can be adjusted by rotating the device.

### D. ACCESS SIM CARD SLOT AND MICRO SD CARD SLOT

1. To access the SIM card slot, lift card compartment cover using bottom notch.
2. To access the microSD card slot, lift card compartment cover using bottom notch.

### E. GETTING CONNECTED

Your device can access the Internet through a wireless network. You can also connect to other wireless devices to share files via Bluetooth.

To connect via **WLAN**:

1. From the settings menu, tap the WLAN ON/OFF button to turn WLAN on.
2. The device will automatically scan for available wireless networks. Tap **WLAN** to display the network names and security settings of the detected wireless networks.
3. Tap the desired wireless network to connect. If you select an open network, you will be automatically connected to the network. If you select a network that is secured with WEP, you will be asked to enter the key and then tap **Connect**.

---

## Getting Started (continued)

---

To connect via **Bluetooth**:

1. When Bluetooth is enabled, the device will automatically scan for available Bluetooth devices. Tap the **Bluetooth** item to display the list of in-range Bluetooth devices.
2. Tap a device from the list to initiate pairing.
3. When prompted, enter the PIN code and then tap OK.
4. Enter your device's PIN code on the other device to accept the pairing.
5. Once the pairing is completed, you can now start sharing data between devices.



[www.janam.com](http://www.janam.com)

*Technology at Work.*<sup>®</sup>



5 6 1 5 N 4 3 5 0 0 1 2 R 0 0